

Carbon Nanotube Tunable Microbattery

Philippe Lacasse
Georgia Tech Research Institute
Electro-Optics Systems Lab

February 9th, 2008



Introduction and Initial Plan

- Based on work by Madou & Wang at UC Irvine (see right).
- Believed we could get better results using CNTs as anodes and cathodes.
- Initial plan was very aggressive
- Project stalled:
 - Choosing the metal to serve as the interdigitated array material
 - Selecting the proper negative photoresist.
 - Both of these steps involve creating new protocol.





Fig. 1. Typical SEM images of (A) SU-8 post arrays (before pyrolysis) and (B) carbon post arrays (after pyrolysis). (a) Galvanostatic charge/discharge cycle behavior of patterned carbon arrays and (b) cyclic voltammetry of patterned carbon arrays.



Microbattery Layout

- Channel Geometry
 - Parallel
 - Diagonal
 - Uniform width and length, varying height.
- Every other channel is connected to a site to be used for wire bonding.
- Differing lengths cause differing resistance profiles across the array.
- Calculated the resistance for short, middle and long digit to get good profile.

Fabrication Tree



Key:

Positive PR Method

Chrome Negative PR Method

Chromeless Negative PR Method

Comparison of Fabrication Processes


	Positive Photoresist Method	Chrome Negative Photoresist Method	Chromeless Negative Photoresist Method
	"Positive Method"	"Chrome Method"	"Chromeless Method"
Spin Photoresist	2	2	2
Pattern Photoresist	2	2	2
Lift Off/Stripping	2	2	2
Deposition/Sputter	2	3	2
Etching	0	3	1
CVD	1	1	1
Total Steps	9	13	10
Advantages	<ul style="list-style-type: none"> • Simplest method. • Fewest process steps. • Able to leverage lab experience. 	<ul style="list-style-type: none"> • Most likely to work correctly. • Negative PR* can be remove without damaging the IA**. • Can use SU-8 Negative Photoresist that we already have. 	<ul style="list-style-type: none"> • Least complicated of the two Negative PR* methods.
Disadvantages	<ul style="list-style-type: none"> • Positive PR* likely to bake in sputterer. 	<ul style="list-style-type: none"> • Most complicated. • Lab has never used negative PR* before. • IA may use untested etchant. • Introduces extra etching steps. 	<ul style="list-style-type: none"> • Negative PR* probably will damage IA** layer. • Lab has never used negative PR* before. • IA may use untested etchant.
Order of Preference	1	2	3

Step 1: Clean and Prepare Substrate

Positive Method

Cross-Section View

Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE

Spin Positive Photoresist
[Spinner]



Step 2: Spin Positive Photoresist

Positive Method









Cross-Section View



Overhead/Plan View



SUBSTANCE

-  SILICON & NATIVE SILICA
-  INTERDIGITATED ARRAY MATERIAL
-  CHROME
-  POSITIVE PHOTORESIST
-  NEGATIVE PHOTORESIST
-  IRON
-  CARBON NANOTUBES
-  ELECTROLYTE

Pattern with Blue Mask
[Mask Aligner, Wet Bench]




Step 3: Pattern with Blue Mask

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE

Sputter Interdigitated Array
Material

[DC Sputterer]



ELECTRO-OPTICAL SYSTEMS
LABORATORY
GEORGIA TECH RESEARCH INSTITUTE




Step 4: Sputter Interdigitated Array Material

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE

Strip Positive Photoresist
[Wet Bench]



Step 5: Strip Positive Photoresist

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE

Spin Positive Photoresist
[Spinner]



Step 6: Spin Positive Photoresist

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE


Pattern with Lucky Charms Mask
[Mask Aligner, Wet Bench]




Step 7: Pattern with Lucky Charms Mask

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE

Deposition of Iron
[Denton Thermal Evaporator]



Step 8: Deposit Iron

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE


Lift Off of Positive Photoresist
[Wet Bench]




Step 9: Lift Off of Positive Photoresist

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE

Dice and CVD

[__?__, First Nano Chemical Vapor Deposition Unit]




ELECTRO-OPTICAL SYSTEMS
LABORATORY
GEORGIA TECH RESEARCH INSTITUTE


Step 10: Dice and CVD

Positive Method

Cross-Section View



Overhead/Plan View



SUBSTANCE

- SILICON & NATIVE SILICA
- INTERDIGITATED ARRAY MATERIAL
- CHROME
- POSITIVE PHOTORESIST
- NEGATIVE PHOTORESIST
- IRON
- CARBON NANOTUBES
- ELECTROLYTE

Add Electrolyte, Casing and Testing

[Wet Bench, Coin Cell Crimper, Electrical Testing Equipment]



Step 11: Add Electrolyte, Casing and Testing

Positive Method









Cross-Section View



Overhead/Plan View



SUBSTANCE



-  SILICON & NATIVE SILICA
-  INTERDIGITATED ARRAY MATERIAL
-  CHROME
-  POSITIVE PHOTORESIST
-  NEGATIVE PHOTORESIST
-  IRON
-  CARBON NANOTUBES
-  ELECTROLYTE

Longest Digit

- Length of digit: 9563 μm



$$R = f(H) = \frac{\rho L}{W} \left(\frac{1}{H} \right)$$

R	[=]	Ω	≡	Electrical Resistance
ρ	[=]	$\Omega \cdot m$	≡	Resistivity
L	[=]	m	≡	Length of Digit
W	[=]	m	≡	Width of Digit
H	[=]	m	≡	Height of Digit





Middle Digit

- Length of Digit: 4454.7718 μm
- Mo can be ruled out as material because of its resistance.
- W and TiN are pretty much the same in resistance, as is TiW and Ti.




Short Digit

- Length of Digit: 203.3 μ m
- Au doesn't make good substrate for CNT growth.
- Chose TiW and TiN.
 - TiW is easy to work with in etching.
 - TiN has better resistance values.




Negative vs. Positive Photoresist

- The shadow mask we have is inverse of what we need.
- When exposed with positive photoresist (what we normally use), it develops the channels.
 - This is good for depositing the channels, but not for etching them.
 - We cannot put the positive photoresist in the sputterer to lay down the metal.
- Need to buy and develop procedure for negative photoresist.
- Develop procedure for stripping.



POSITIVE PHOTORESIST NEGATIVE PHOTORESIST



Future Decisions

- Wet etching? Plasma etching?
- Learn to align “Lucky Charms” mask with the “Blue” mask (through positive photoresist).
- Grow CNTs with AcUHYCNT820 (30 mins) recipe.
- Wire bonding.
- Use LabView and new electrical testing equipment to characterize the samples.

